

Arc Welder

1. Use a shade 10 to 12 in the welding helmet and clean the observation window periodically.
2. Safety Glasses must be worn under the welding hood.
3. Keep sleeves and pants cuffs rolled down.
4. Goggles must be worn for all chipping operations.
5. Keep all flammable material away from working areas.
6. Always wear leather gloves, apron, and leather topped shoes when welding.
7. Wearing a welding cap under the hood for added protection in out of position welding.
8. The floor area should be dry and kept clear of all obstructions.
9. Closed containers should not be welded without the instructor's permission.
10. Report any overheating of the welding unit to the instructor at once.
11. Screens to protect others must be in place before welding is started.
12. The exhaust system must be turned on prior to welding.
13. Keep your head out of the weld smoke plume
14. Avoid tripping hazards. Dispense used arc rods (2" long) into a container and not on the floor.

